



# *e-light-1000-4GM*

Art. No.: 0510X 10 XX XX



eks Engel FOS GmbH & Co. KG  
Schützenstrasse 2-4  
57482 Wenden-Hillmicke  
Germany

Tel.: +49 (0) 2762 9313-600  
Fax: +49 (0) 2762 9313-7906  
E-mail: [info@eks-engel.de](mailto:info@eks-engel.de)  
Internet: [www.eks-engel.de](http://www.eks-engel.de)

	<h1>Operating Manual</h1>	MAN_EL-1000-4GM
		Version: 2.6.1 / 01.02.2021
		Authorized by: T.W.
		Page 2 of 77

## Legal notice

This manual contains important notes and warnings that could lead to serious personal and property damage if ignored. Please read this manual carefully prior to commissioning the **EL-1000-4GM** switches. Correct transport, correct storage, and installation and careful operation and maintenance of the **EL-1000-4GM** are critical for safe operation.

## Intended use

The devices in the **EL-1000-4GM** product family may only be operated as described in this manual. These may only be used free of damage and according to the indicated environmental conditions. The enclosure of the **EL-1000-4GM** may only be opened by eks technicians; the devices do not contain any components that must be maintained by the customer. The ETHERNET connections are only intended for connection to computer networks (LANs) and must not be connected to telephone networks or telecommunication lines.

## Personnel requirements

Installation and commissioning of the **EL-1000-4GM** may only be completed by trained personnel who are familiar with this operating manual. Furthermore, all work on electrical systems may only be completed by an electrician or under their direction and supervision. Applicable local and national safety conditions must be maintained at all times.

## Voltage supply

The devices in the **EL-1000-4GM** product family have been designed for operation with NEC Class 2 conform voltage supplies.

The shielding of the RJ45 sockets is connected with the enclosure of the **EL-1000-4GM** to discharge faults. Note any possible short circuits when using shielded cables.

## Laser equipment safety

The devices in the **EL-1000-4GM** product family include LED or LASER components as per IEC 60825-1 (2014): class 1 laser/LED product.

### Warning!

Do not use optical instruments (e.g. lenses, microscope) to look into the beam of the optical transceivers! Ignoring this warning may result in eye damage.



## CE conformity

The devices in the **EL-1000-4GM** product family match the regulations of the EU guideline

**2014/30/EU**

**Directive of the Council... regarding electromagnetic compatibility**

with the following standard and standardizing documents in the currently applicable version:

<b>DIN EN61000-6-2</b>	<b>Electromagnetic compatibility (EMC) – part 6-2:</b>
	<b>Generic standards – Immunity for industrial environments</b>
<b>DIN EN55032 cl. A:2016-2</b>	<b>Information technology equipment</b>
	<b>Radio disturbance characteristics – Limits and methods of measurement</b>

### Warning!

This is a class A product. It may cause radio disturbances in living areas; in this case, the operator can be required to take appropriate measures and to be responsible for these.

The installation instructions in this manual must be followed exactly so that the EMC threshold values indicated are maintained.

### Disposal notes

The devices must not be disposed with normal household waste but can be returned to eks Engel FOS GmbH & Co. KG for disposal.

WEEE-identification: DE 900 53 255



	<h1>Operating Manual</h1>	MAN_EL-1000-4GM
		Version: 2.6.1 / 01.02.2021
		Authorized by: T.W.
		Page 4 of 77

# Foreword

---

## Overview of the *EL-1000-4GM* product family

The devices in the *EL-1000-4GM* product family are industrial Ethernet switches including management features that can be configured comfortably and easily via a web application. These enable low-cost installation of industrial Ethernet bus, star, and ring structures with switching functionality.

In addition to the basic version of the *EL-1000-4GM*, which is delivered without fiberoptic connections, there are versions with two or four fiberoptic connections. These devices can be equipped with the most diverse transceivers for single mode or multi-mode featuring plug connector types ST or SC.

## Properties

- » Web application for configuration
- » Redundant voltage supply 12 VDC to 60 VDC with reverse voltage protection
- » Monitoring of individual input voltages via configurable alarms
- » Two relay contacts controlled via configurable alarms
- » 10BASE-T/100BASE-TX (RJ45) and 100BASE-FX (MM or SM)
- » PHY and MAC completely compatible to IEEE 802.3, IEEE802.3u, and IEEE 802.3x
- » Auto MDI/MDI-X crossover function for 100BASE-T and 10BASE-T ports
- » Store-and-forward switching architecture with 2048 MAC address table
- » Quality of Service (QoS) with four priority queues
- » Prioritize via IEEE 802.1p Class of Service (COS), Type of Service (TOS)/DiffServ or port priority
- » Limitation of incoming and outgoing packets
- » Port mirror for TX or TX and RX packets
- » Port-based VLAN/802.1Q Tagged VLAN
- » Simple Network Time Protocol (SNTP)
- » Simple Mail Transfer Protocol (SMTP) for signaling alarms
- » Internet Gateway Management Protocol Snooping (IGMP Snooping)
- » Dynamical Host Configuration Protocol (DHCP) client function

- » Simple Network Management Protocol (SNMP)
- » Update, save, and back up the system configuration via TFTP, HTTP and USB
- » Profinet (Conformance Class B, Netload Class III)

**Note:**

Depending on the version of the programmed software, devices can be delivered featuring other functions.

# 1 Table of contents

---

<b>Legal notice .....</b>	<b>2</b>
Intended use .....	2
Personnel requirements .....	2
Voltage supply .....	2
Laser equipment safety .....	3
CE conformity .....	3
<b>Foreword .....</b>	<b>4</b>
Overview of the <i>EL-1000-4GM</i> product family.....	4
Properties .....	4
<b>1 Table of contents .....</b>	<b>6</b>
<b>2 Hardware Description .....</b>	<b>11</b>
2.1 Front view .....	11
2.2 Reset button .....	12
2.3 DIP switches.....	12
2.4 LED displays .....	12
2.5 Ports .....	15
2.5.1 RJ-45 ports.....	15

2.5.2	Optical ports .....	15
2.5.3	Wiring .....	15
2.5.4	Voltage supply connection.....	15
2.5.5	Failure relay connection .....	16
2.6	Installation on DIN mounting rail .....	17
2.7	Dimensions .....	19
<b>3</b>	<b>Config-Mode .....</b>	<b>20</b>
3.1	Config-Mode usage .....	20
3.2	Config-Mode options .....	21
3.2.1	Overview .....	21
3.2.2	Leave without changes .....	22
3.2.3	Activate default IP settings .....	22
3.2.4	Delete IP settings.....	22
3.2.5	Block access to the Management interface .....	22
3.2.6	Allow access to the Management interface .....	22
3.2.7	Disable Profinet functionality .....	22
3.2.8	Enable Profinet functionality .....	22
<b>4</b>	<b>Network topologies/redundancy .....</b>	<b>23</b>
4.1	Star structure .....	23

4.2	Meshed networks .....	24
4.3	Ring structure .....	25
<b>5</b>	<b>Web application.....</b>	<b>26</b>
5.1	Preparations .....	26
5.2	System login.....	27
5.3	Web interface .....	28
5.3.1	Menu bar.....	28
5.3.2	Information bar .....	28
5.4	System information .....	29
5.4.1	Status and diagnosis .....	29
5.4.2	Alarms/Notifications.....	29
5.4.3	Port statistics.....	32
5.4.4	Syslog messages .....	34
5.4.5	Link Layer Discovery protocol – topology .....	36
5.5	Basic settings .....	39
5.5.1	IP configuration .....	39
5.5.2	Password.....	41
5.5.3	Time setting.....	42
5.6	Port configuration.....	45



5.6.1	Port Mirroring.....	46
5.7	Redundancy .....	48
5.7.1	Media Redundancy Protocol (MRP).....	48
5.7.2	Rapid Spanning Tree Protocol (RSTP).....	49
5.8	Industrial Protocols.....	54
5.8.1	Profinet.....	54
5.9	Switching .....	55
5.9.1	IGMP Snooping.....	55
5.9.2	VLAN 802.1Q .....	56
5.9.3	Quality of Service (QoS).....	59
5.9.4	Rate Control .....	61
5.10	Access .....	63
5.10.1	Simple Network Management Protocol (SNMP) .....	64
5.11	Maintenance .....	66
5.11.1	Backup .....	66
5.11.2	Restore .....	66
5.11.3	Restore via USB stick.....	68
5.11.4	Firmware update .....	68
5.11.5	Factory settings.....	70
5.11.6	Reboot.....	70

	<h1>Operating Manual</h1>	MAN_EL-1000-4GM
		Version: 2.6.1 / 01.02.2021
		Authorized by: T.W.
		Page 10 of 77

5.11.7 Licenses .....	70
<b>6 Instructions for troubleshooting.....</b>	<b>72</b>
<b>7 Technical specifications.....</b>	<b>73</b>
<b>8 GPL/LGPL guarantee and liability exclusion .....</b>	<b>74</b>
<b>9 Table of figures .....</b>	<b>76</b>

## 2 Hardware Description

The front of the *EL-1000-4GM* switches is equipped with extensive displays, which provide information concerning the current status of the devices. In addition to USB data line connections and the RS232 line for configuration, there is also a reset button for resetting the device to the factory settings in case of an unknown IP address and a labeling field for entering the programmed IP address.

### 2.1 Front view




Figure 1: Front view of the *EL-1000-4GM* switch with 2 LWL transceivers

	<h1>Operating Manual</h1>	MAN_EL-1000-4GM
		Version: 2.6.1 / 01.02.2021
		Authorized by: T.W.
		Page 12 of 77

## 2.2 Reset button

The reset button can be used to restart the switch or to reset the configuration to the initial value:

- » **Restart:** Hold the button pressed down for 5 seconds and release it as soon as all LEDs light up. The switch is now restarted.
- » **Config-Mode:** (see chapter 3 Config-Mode)
- » **Reset to initial value:** Hold down the button for 10 seconds. The switch resets the complete configuration to the standard settings and signals this after shutting off all LEDs briefly.

## 2.3 DIP switches

Devices manufactured up to 31.07.2018 had a 9-pin DIP switch on the front, without function. From 01.08.2018 manufactured **EL-1000-4GM** devices are delivered without DIP switches.


## 2.4 LED displays

The front panel of the switch features 5 diagnosis LEDs. Furthermore, each of the RJ45-ports features two status LEDs. The LED displays offer real-time information regarding the status of the **EL-1000-4GM**, see Table1.

LED	Status	Meaning
VDC1	Green	The VDC1 connection possesses sufficient voltage (>= 12VDC)
	Off	The VDC1 connection does not possess sufficient voltage
VDC2	Green	The VDC2 connection possesses sufficient voltage (>= 12VDC)
	Off	The VDC2 connection does not possess sufficient voltage
Ring	Green	The switch is the manager in the MRP ring
	Off	The switch is not the manager in the MRP ring
Status	Green	Profinet-AR-Status Online
	Off	Profinet-AR-Status Offline
Fault	Red	Configured alarm active
	Off	No alarm condition fulfilled

LED	Status	Meaning
<b>LNK/ACT</b> <b>(Optical port)</b>	Green	Connection available
	Blinking	Sending or receiving packets
	Off	No connection
<b>FDX</b> <b>(Copper port – RJ45)</b>	Green	Full duplex mode
	Off	No connection (LNK/ACT off) or half-duplex (LNK/ACT on)
<b>LNK/ACT</b> <b>(Copper port – RJ45)</b>	Yellow	Connection available
	Blinking	Sending or receiving packets
	Off	No connection available

Table1: LED description

	<h1>Operating Manual</h1>	MAN_EL-1000-4GM
		Version: 2.6.1 / 01.02.2021
		Authorized by: T.W.
		Page 15 of 77

## 2.5 Ports

### 2.5.1 RJ-45 ports

The **EL-1000-4GM** features eight RJ-45 ports, depending on the design, each with transfer rates of 10 mbps , 100 mbps or 1000 mbps. The ports detect the data rate automatically. Sending and receiving lines are crossed appropriately via MDI/MDI-X auto-crossover so that connections are able to be established with other devices, independent of the cable type used (1:1 or crossed).

### 2.5.2 Optical ports

The **EL-1000-4GM** is equipped with up to two 1000Base-FX ports, depending on the design. Depending on the variation ordered, the LWL ports may have SFP slots or SC- plug connectors and be suitable for different fiber types (multi-mode, single-mode).

Please make sure that the transceivers of the **EL-1000-4GM** are always connected with transceivers of other devices that are suitable for the same wavelength and the same fiber type.

With the exception of Bidi transceivers, which cannot send and receive simultaneously via one fiber, the transmitters of a device must always be connected with the receiver of the opposite device and vice-versa.

### 2.5.3 Wiring

- » Use twisted-pair cable of category 5 or better to connect the RJ-45 ports. The electrical connection cable between the switch and the connection partner (switch, hub, workstation, etc.) may not be longer than 100 meters. Use metal shielded connectors on the cables.
- » Connect the multi-mode transceiver with 50/125 µm or 62.5/125 µm multi-mode optical fiber cables.
- » Connect the single-mode transceiver with 9/125 µm single-mode optical fiber cables.

### 2.5.4 Voltage supply connection

Connect the supply voltage to VDC1 and GND clamping terminals. The redundant supply voltage may now be connected to the VDC2 and GND clamping terminals. The terminal block for the voltage supply is clamping and can be locked using two screws. Both voltage inputs feature reverse voltage protection.

The permissible range for the input voltage is between 12 VDC and 60 VDC. The voltage must be

SELV/LPS-conform voltage as per IEC 60950-1/EN60950-1/VDE0805-1. Please observe the instructions for SELV voltages according to the legal instructions at the beginning of this operating manual.





Figure 2: VDC connection terminal

**Note:** Please tighten the screws and check that all connections are stable.

**Note:** Please note the corresponding cable cross-section of at least 0.5 mm<sup>2</sup> or 12~ 24 AWG during wiring.

### 2.5.5 Failure relay connection

Between the terminals labeled  there is a potential-free fault relay contact. The relays act as alarm receivers and can be connected in the software with different alarm triggers. Depending on the configuration, they activate, for example, in case of a voltage failure, RJ45 port error or a LWL port error. In the software, the relay is marked relay 1.

**Note:** The capacity of the relay contact amounts to 25 VDC (1A) or 60 VDC (0.3A).



## 2.6 Installation on DIN mounting rail

The **EL-1000-4GM** switches are equipped with a fastener for 35 mm top-hat rails as per DIN EN 60175. To install the top-hat rails, snap the devices onto the top side of the rail (Figure left) and then press downward against the spring force in the top-hat rail clip (1) and then into the assembly plate (2). The top-hat rail fastener locks via spring force (3) as depicted in the Figure right.




Figure 3: Installation on DIN mounting rail

To remove the device from the DIN rail, press the housing down (overcome the spring force of the DIN rail clip), then pull the device towards you and remove it from the mounting rail.

## Warning!

Do not mount **EL-1000-4GM** switches directly beside devices that produce strong electromagnetic interference fields, e.g. transformers, contactors, frequency inverters, etc.

## Warning!

Do not mount **EL-1000-4GM** switches directly next to heat producing devices and protect the switch against direct sunlight in order to prevent unwanted heating.

## Warning!

When operating in ambient temperatures above 60°C, the enclosure of the **EL-1000-4GM** switches may heat above 70°C. Do not install the devices in areas that are accessible by unqualified personnel.

## Warning!

When operating in ambient temperatures above 60°C, measurements must be taken to check how severely the plug connectors of the cables used heat up. Use of special cables that are suitable for ambient temperatures above 80°C may be required.

## Note:

In case of use on ships, **EL-1000-4GM** switches may not be fastened with the top-hat rail fastener on a 35 mm rail. The top-hat rail does not provide secure mounting. On ships, **EL-1000-4GM** switches must be fastened using the wall installation mounting.

## Note:

In order to meet the climatic conditions in operation, it must be ensured when installing the device that the minimum distance to neighboring devices is not exceeded.

»» Minimum distance above and below the device: 10 cm

»» Minimum distance to the right and left of the device: 2 cm

If the minimum distance is not reached, the maximum operating temperature defined in the "Technical specification" chapter is reduced.

	<h1>Operating Manual</h1>	MAN_EL-1000-4GM
		Version: 2.6.1 / 01.02.2021
		Authorized by: T.W.
		Page 19 of 77

## 2.7 Dimensions

Fehler! Verweisquelle konnte nicht gefunden werden. zeigt die Abmessungen des **EL-1000-4GM**.

Figure 4: Dimensions of the EL-1000-4GM switch

	<h1>Operating Manual</h1>	MAN_EL-1000-4GM
		Version: 2.6.1 / 01.02.2021
		Authorized by: T.W.
		Page 20 of 77

## 3 Config-Mode

---

By utilizing the reset button and status LEDs of the device, **EL-1000-4GM** switches can be configured without having access to the Web interface using the Config-Mode.

### 3.1 Config-Mode usage

The Config-Mode is activated by tapping the Reset button 3 times within a 2 second time window. Once it active, the green Ring LED starts flashing.

To switch between the different available options the reset button has to be tapped again. With each tap the mode switches on until the last option is active. If the button is pressed again, the Config-Mode switches back to the first option.

To leave the Config-Mode the reset button has to be pressed for at least 2 seconds without being released.

Once the Config-Mode is exited, the selected option is executed.

The settings in Config Mode do not cause the connection to be interrupted. Communication between the connected devices continues undisturbed.

## 3.2 Config-Mode options

### 3.2.1 Overview

Falshing LEDs	Meaning
Ring	Leave without changes
Status	Activate default IP settings
Ring + Status	Delete IP settings
Fault	Block access to the Management interface
Ring + Fault	Allow access to the Management interface
Status + Fault	Disable Profinet functionality
Ring + Status + Fault	Enable Profinet functionality

	<h1>Operating Manual</h1>	MAN_EL-1000-4GM
		Version: 2.6.1 / 01.02.2021
		Authorized by: T.W.
		Page 22 of 77

### 3.2.2 Leave without changes

Upon activation of this option, Config-Mode is exited without performing any changes.

### 3.2.3 Activate default IP settings

Upon activation of this option the following changes will be made:

- The device's IP address is set to 192.168.10.1
- The device's subnet mask is set to 255.255.255.0
- The device's default gateway is set to 0.0.0.0
- The DHCP mode is deactivated

### 3.2.4 Delete IP settings

Upon activation of this option the following changes will be made:

- The device's IP address, subnet mask and default gateway are set to 0.0.0.0
- The DHCP mode is deactivated

### 3.2.5 Block access to the Management interface

Upon activation of this option the following changes will be made:

- The device's IP address, subnet mask and default gateway are set to 0.0.0.0
- The DHCP mode is deactivated
- All Profinet functionality is disabled

### 3.2.6 Allow access to the Management interface

Upon activation of this option the following changes will be made:

- The device's IP address is set to 192.168.10.1
- The device's subnet mask is set to 255.255.255.0
- The device's default gateway is set to 0.0.0.0
- All Profinet functionality is enabled

### 3.2.7 Disable Profinet functionality

Upon activation of this option all functionality regarding Profinet is disabled.

### 3.2.8 Enable Profinet functionality

Upon activation of this option all functionality regarding Profinet is disabled.

## 4 Network topologies/redundancy

The devices in the *EL-1000-4GM* product family can be used with various protocols in addition to use in star-shaped switched-Ethernet networks and in redundant networks such as meshed networks or rings.

### 4.1 Star structure

Classic Ethernet star structures, see Figure 5, can be networked using devices in the *EL-1000-4GM* product family without additional configuration. The devices are immediately ready to function.




Figure 5: *EL-1000-4GM* in a star-shaped network

## 4.2 Meshed networks

Use of the Rapid Spanning Tree protocol (RSTP) enables any Ethernet structures to be built, for example, as displayed in Figure 2. STP and RSTP break these structures up into a tree structure and reconfigure this tree structure in case of changes to the topology. The reconfiguration time is typically less than 1 s for Rapid Spanning Tree.




Figure 2: *EL-1000-4GM* in a meshed network



## 4.3 Ring structure

The *EL-1000-4GM* supports the Media Redundancy Protocol as per IEC 62439 (MRP ring), which enables the system to recover from network failures within 200 ms or less. The MRP ring increases the reliability of the network in this way. Figure 3 shows an example for use with ring functionality. The switch can be configured as Manager and Client.




Figure 3: *EL-1000-4GM* in a ring-shaped network

## 5 Web application

---

**EL-1000-4GM** switches are equipped with a modern web interface so that they can be configured conveniently using any web browser.

### 5.1 Preparations

Before you use the web management feature, install the **EL-1000-4GM** switch in the network and ensure that the PC intended for configuration of the switch is in the same subnet to be able to access the switch via the web browser. The device credentials set upon delivery are available here:

» User name: **admin**

» Password: **admin**

Alternatively to administrator access, guest access with fewer permissions and adjusted menu guidance is also available. The guest user does not have access to the switching and maintenance functions and their sub-items. The access data are:

» User name: **guest**

» Password: **guest**

**Note:**

Please change the passwords of the admin and guest users, before you use the device in your network.

With factory settings the device has no IP-Address set. In Profinet-Projects please set the IP-Address with the Automation Framework (e.g. TIA Portal). In non Profinet applications setup tools that are capable of setting Device-Names and IP-Addresses via DCP may be used (e.g. Profinet Commander)<sup>1</sup>. The device can also be configured using the Config mode.

---

<sup>1</sup> <https://profinetcommander.com/>

## 5.2 System login

1. Start a web browser on your computer.
2. Enter the configured IP address of the **EL-1000-4GM** switch used by you and then press the “Enter” key.
3. The login mask of the device now appears on the screen.




Figure 8: Login Window

4. Select the desired menu language.
5. Now enter the user name and password.
6. Press the “Enter” key or click “Login”. You will now enter the web interface for the switch.

## 5.3 Web interface

The web interface of the *EL-1000-4GM* comprises the menu bar on the left edge, the information bar in the top area, the actual configuration in the center, and the help on the right edge, see Figure 4.

### 5.3.1 Menu bar

The menu guide enables you to access the individual screens and complete settings there. The menu items displayed are divided into additional sub-items.

### 5.3.2 Information bar

The information bar shows you the device type, Profibus name, location, and the IP address. The current user is shown under the logout button on the right end of the bar. By pressing the button, you can log out and lock the webgui of the device. The help button shows instructions and explanations for the individual screens.




Figure 4: Status and diagnosis

	<h1>Operating Manual</h1>	MAN_EL-1000-4GM
		Version: 2.6.1 / 01.02.2021
		Authorized by: T.W.
		Page 29 of 77

## 5.4 System information

The system information screen offers you a complete overview of the status and current configuration of the **EL-1000-4GM**.

### 5.4.1 Status and diagnosis

On the actual status and diagnosis screen, an overview displays the currently activated and deactivated protocols and functions in addition to the serial number, hard and software version of the device. With the help of the editing buttons, you can directly change to the corresponding protocols and functions to change the settings there.

### 5.4.2 Alarms/Notifications

The menu item alarms/notifications is used to define alarm triggers and alarm receivers. Alarm triggers indicate which alarms of the software should be observed. If alarms occur for which an alarm trigger is defined, then a log entry will be created and the Fail LED will be activated. In turn, alarm receivers connected with the alarm trigger are informed or activated. Alarm triggers include, for example:


- » a status change at a port
- » temperature that is too high or too low
- » a supply voltage outage
- » Media Redundancy Protocol Error
- » Wrong Neighbor in Profinet-Projects

Alarm receivers are:

- » two error relays
- » SNMP traps
- » E-mail addresses

The configured alarm assignments are displayed in lists with sequential IDs.

With the help of the alarm trigger and alarm receiver screen tabs, the view can be switched between:


	<h1>Operating Manual</h1>	MAN_EL-1000-4GM
		Version: 2.6.1 / 01.02.2021
		Authorized by: T.W.
		Page 30 of 77

- » Alarm trigger with assigned receiver
- » Alarm receiver with assigned trigger

### Add and edit alarm trigger

The alarm trigger screen tab (Figure 50) enables new alarms to be added by clicking the "+" button. If alarms are already present, then they can be edited or deleted using the button on the right in the table. When adding and editing alarms, the associated receiver can be selected in the lower part of the screen and linked to the alarm trigger in this way. The following alarm triggers are possible:

- » The Ethernet ports can trigger an alarm in case of activity, inactivity, and status change.
- » The optical ports may also report a weak signal in addition to activity, inactivity, and a status change.
- » Alarms can be configured if an upper temperature limit is exceeded or if a lower temperature limit dropped below.
- » The input voltages can be monitored individually. If one or both voltages are below 12 VDC, then an alarm can be triggered.
- » MRP events (ring interruption, ring connected again, generic warning) may create an alarm.
- » The device is connected to another device than configured in the Automation Portal. (Wrong Neighbor



**Figure 50: Alarms/notifications: Adding an alarm trigger**

### Add and edit alarm receiver

By clicking the "+" buttons below the alarm receiver screen tab (Figure 61), new receivers can be added. Both relays are already available as alarm receivers and may not be deleted, but rather only linked with alarm triggers. SNMP traps and e-mail in-boxes can be added as new alarm receivers.

» With the simple network management protocol (SNMP), the generated error messages of the device (which acts as agent) are sent to the management station which IP-address is specified in the field "Trap receiver IP". The receiver will not send acknowledgement messages. So there is no guarantee that the trap receiver received the information. Furthermore you have to define a community string to ensure the communication between the management station and the agent.

The settings will be confirmed by clicking the Create button.

» With the email notification, administrators can be notified about error. Enter an email address and a SMTP-server IP (simple mail transfer protocol) to configure receivers. The

device will send email messages if a configured alarm is triggered. If required set up authentication credentials according to your needs. For this you have to select the checkbox “Authentication needed:” and define a SMTP password. Optionally, the encryption can be activated by selecting the checkbox. Subsequently, the port and the type of encryption can be defined.

The setting will be confirmed by clicking the Create button.

With the Button “Send test email” you can verify if the email setup works before the alarm receiver is created.

In the lower part of the screen, the alarm receivers can be assigned to previously added alarm triggers.




Figure 61: Adding an alarm receiver

### 5.4.3 Port statistics

The port statistics screen (Figure 72) provides information about the data traffic on the individual ports, which is helpful for diagnosis purposes in case of network problems. The complete number of sent, received, faulty, and colliding packets is displayed. Furthermore, the size of the individual packets is recorded statistically up to a variety of threshold values.



	<h1>Operating Manual</h1>	MAN_EL-1000-4GM
		Version: 2.6.1 / 01.02.2021
		Authorized by: T.W.
		Page 33 of 77

Sent packets are differentiated in terms of:

- » Number of packets
- » Number of Unicast packets (packets to one receiver)
- » Number of non-Unicast packets (packets to multiple receivers)

Received packets are differentiated in terms of:

- » Number of all packets
- » Total number of bytes received
- » Total number of fragments received

The CRC errors column provides information about the number of faulty received data packets. The cyclical redundancy test, CRC (Cyclic Redundancy Check), specifies a test value using the transferred data. This value is sent together with the data and evaluated by the receiver. Fault packets are detected and discarded in this way.

The total number of all collisions and the late collisions are displayed in the collisions column.

The packets up to bytes column provides information about the number of packets in diverse sizes. In this case, the number of packets received up to 64, 127, 255, 511, 1023, or 1518 bytes in size is recorded.

### **Update and reset the values**

In the status bar arranged above the table, the table can be updated by pressing a button. Using a second button, the option is available to reset the counters of all ports and start a new evaluation in this way. The time at which the evaluation was started is displayed in the status bar as the last reset.

### **Sort and hide the entries**

The port statistics offer valuable information about the network diagnosis. In order to simplify the diagnosis, the option is available to limit the display to the important columns.

Individual columns can be hidden or sorted for this purpose using pull-down menus in the table labels.





Figure 72: Port statistics

## 5.4.4 Syslog messages



	<h1>Operating Manual</h1>	MAN_EL-1000-4GM
		Version: 2.6.1 / 01.02.2021
		Authorized by: T.W.
		Page 35 of 77

Figure 83) provide the user help for receiving status and error messages about the various functions and protocols. The messages are displayed in the overview including the date and time, plus a code, a description, and a reference. Because the log entries are not saved in the device, they are no longer available after the device is restarted or if the voltage is interrupted. In order to archive the messages permanently, the option is available to use an external Syslog server.

### Using the Syslog server

In order to archive the messages on a Syslog server or to save them, activate this function via the selection field in the top bar. Enter the IP address of the Syslog server in decimal points and save the settings using the apply button that appears below. Please check if the server is able to be reached and if the messages are being saved in a file.

### Update, export, and reset the entries

The following buttons are available for this:

- » Using the update button in the status bar arranged above the table, the table can be reloaded.
- » The CSV export button creates a CSV file (Comma-Separated Values) including all entries from the table and saves these in the download folder of the browser. The messages are written in a file separated into rows by a comma.
- » The button for deleting the log file removes all entries from the table. After that all messages that occurred after this time are shown. The time that the entries were deleted is visible via the first log entry that appears.

### Sort and hide the entries

The individual columns of the Syslog messages can be hidden or sorted for using pull-down menus in the table labels.







Figure 83: Syslog messages

### 5.4.5 Link Layer Discovery protocol – topology

The Link Layer Discovery protocol (menu see Figure 94) is a manufacturer-independent Layer-2 protocol, which is defined as per the IEEE-802.1AB[1] standard and offers the option to exchange information between neighboring devices. On every device that supports the LLDP, a software component operates as the so-called LLDP agent. This sends information in periodic intervals concerning the actual status and receives information from neighboring devices permanently. Because this occurs independently of each other, the LLDP is also referred to as a one-way protocol. Before sending the information, no connection to the other devices is established.

The following information is compiled by the LLDP and sent:


-  System name
-  System description
-  Port description

- » Chassis ID
- » IP-Address

System name, System description and Port description are set according to the values given in SNMP-MIB2. These values are read-only. The Chassis ID is the assigned Profinet device Name. In case no device name is assigned the MAC-Address is transmitted. The IP-Address is automatically set to the current device IP

### LLDP interval

The LLDP interval parameter can be used to specify the time intervals (in seconds) in which the device sends its own LLDP telegram to the neighboring devices.



**Navigation:** System Information, Alarms / Notifications, Port Statistics, Syslog Messages, FiberView, **LLDP - Topology**, Basic Settings, Port Configuration, Redundancy, Industrial Protocols, Switching, Access, Maintenance

**Header:** Name of Station: dut, Device Location: admin, IP Address: 192.168.0.50, Help

### Link Layer Discovery Protocol (LLDP) - Topology


ON Current Status: ✓ active

Current ascertained topology

Port	IP Address	Description
1		
2	192.168.0.98	d; port-001
3	192.168.0.254	entwicklung5; port-001
4	192.168.0.99	b; port-003
5		
6		
7	192.168.0.97	e; port-001
8		

Settings

LLDP Interval [s]:



**Figure 9: Link Layer Discovery protocol (LLDP)**

- » On / Off switch: The LLDP can be switched on or off using the switch.
- » Save settings: The settings can be saved by clicking on the "Apply" button under the LLDP interval setting. If the Cancel button is clicked, the new settings are discarded. Both buttons are only visible when a setting on the page has been changed.

## 5.5 Basic settings

The basic settings screen (Figure 5) offers you the option to assign the device a clear name, a location, and a contact partner.

- » Device name: Assign the *EL-1000-4GM* a name to clearly identify the device.
- » Location: The location provides you an additional option for identifying the device.
- » Contact partner: A contact partner responsible for the device can be saved in the third field.

The input fields are configured so that up to 50 characters can be used. At least one character has to be set. The use of special characters is possible. The location is displayed in the information bar in the above right and helps you to assign the web interface to a device.




Figure 15: The basic settings of the *EL-1000-4GM*

### 5.5.1 IP configuration

You can either execute the IP configuration (see


	<h1>Operating Manual</h1>	MAN_EL-1000-4GM
		Version: 2.6.1 / 01.02.2021
		Authorized by: T.W.
		Page 40 of 77

Figure 106) automatically with the help of the Dynamic Host Configuration Protocol (DHCP) or adjust the settings manually.

### Automatic

In order to receive a configuration for the IP-Address, the subnet mask and the standard gateway from a server working in the network with the corresponding functionality, activate the DHCP client function.

After you have saved the settings by clicking the apply button, the device sends a query to the network and accepts the configuration received by the DHCP server. Because the device has now received a new IP address, it is no longer able to be reached via the previously configured IP. Please contact your network administrator to receive a new IP address.

### Manual


If your network does not possess a DHCP or BootP server, or if the settings should be made by hand, then select the manual IP configuration via the top area of the screen. Please check exactly which settings you change so that problems involving duplicate IP addresses do not result, since these could have a negative influence on the entire network. The format of the IP address, the subnet mask, and the gateway must be entered in decimal point format. The following settings are required:

- » IP address: Please note that the set IP address must be able to be reached from your PC so that you can connect again with the device in order to make additional settings.
- » Subnet mask: Enter the subnet mask IP address; this separates the IP address into a network component and a device component. This specifies which IP addresses are able to be reached in the network and which addresses are located in other subnets and only accessible via routers.
- » Gateway: Specify the standard gateway of switches. The gateway is used to communicate with devices outside of the subnet.

### PROFINET-DCP

If you configure the device in a profinet project the IP-Address is set with the DCP-Protocol by the Profinet-Controller depending on the device name. If the device has an active connection to a Profinet-Controller it is not possible to set the IP-Address in the Webinterface.





**Figure 106: Changes to the IP configuration**

## 5.5.2 Password

On the password screen (Figure 117), the pre-set standard password for administrator and guest user can be changed. The current or former password must be known and entered. The user names and rights of the administrator and guest are specified permanently and cannot be changed.

**The following form fields are available:**

- New password: Please enter the password specified by you in this field for the previously selected user. Please also note the instructions for providing passwords in the section below.
- Confirm the password: To ensure that you have entered your password correctly, repeat the input in this field.
- Current password: Please enter the password used up until now, which should now be changed.

## Instructions concerning passwords

The safety of your system depends significantly on the security of your passwords. For passwords, we therefore generally recommend:

- » Do not use dictionary entries
- » Please use passwords that are as complex as possible
- » Combine letters, numbers, and special characters
- » Use lower case and capital letters
- » Your password should consist of at least eight characters
- » Do not write down the passwords




Figure 117: Change the password for administrator and guest access

## 5.5.3 Time setting

The status bar in the top area of the screen for setting the time (Figure 12) displays the system time and the date. The device running time is featured in the center. The far right features the currently

applied settings for the time zone and any possible offset due to daylight savings.

When setting the date and time, select between the use of a time server and manual configuration. The automatic configuration of the system time via Simple Network Time protocol (SNTP) has the advantage that the time setting is updated in regular intervals. An exact system time is especially sensible if the log file should be evaluated in case of a fault.

### Set system time automatically via SNTP

In order to set the system time via SNTP, a connection to an SNTP server on the Internet is required. The following settings are required when using SNTP:


- » SNTP server IP address: Enter the IP address of a time server that can be reached on the Internet or locally. Please use the decimal point format.
- » SNTP server IP address (redundancy): In this field, you may enter the IP address of a second, redundant time server. If the first server is not able to be reached, then the time will be synchronized via this SNTP server.
- » Update interval: Please enter the time intervals at which the device should synchronize with the time server here. In this case, note that the system time may possibly deviate severely from the real time in case of large time spans.
- » Time zone: Please enter the time zone where the device is located.

### Set the system time by hand

If the system time is set by hand, then you have the option of using the browser time or entering the time and the date by hand and saving this.

To use the browser time, press the use browser time button, check the correct time/date, save the correct date/time and save the values with the apply button.

If you want to set the date by hand, select the current date first via the input field. You can also enter the date with the help of the keyboard: first two digits for the month, then two for the day, and finally two or four digits for the year. Enter the time and the corresponding time zone and check if everything has been accepted correctly. Save the settings using the apply button.



**Figure 12: Time settings configuration**


## Daylight savings settings

If you would like to use the automatic changeover between winter and daylight savings time, activate the daylight savings time option.

- » Beginning: Define the date and time when summer daylight savings should start.
- » End: Define the date and time that summer daylight savings should end and the time to change to normal time again.
- » Offset: Please enter the time offset between summer daylight savings and the standard time.

## 5.6 Port configuration

The table for the port configuration (Figure 13) provides an overview of the current configuration of the individual ports. The columns Activated, Auto Negotiation, Flow Control, and Designation may also be configured. The remaining fields are partially changed by configuring the ports and updated by reloading the screen, or they provide an improved overview.













Port	Type	Enabled	Status	Auto Negotiation			MDI(X)	Flow control	Description
				Enabled	Speed	Duplex			
1		<input checked="" type="checkbox"/>	<span style="color: red;">●</span>	<input checked="" type="checkbox"/>	10 mbps	half	MDI	<input type="checkbox"/>	TX-Port 1
2		<input checked="" type="checkbox"/>	<span style="color: green;">●</span>	<input checked="" type="checkbox"/>	100 mbps	full	MDI	<input type="checkbox"/>	TX-Port 2
3		<input checked="" type="checkbox"/>	<span style="color: red;">●</span>	<input checked="" type="checkbox"/>	10 mbps	half	MDI	<input type="checkbox"/>	TX-Port 3
4		<input checked="" type="checkbox"/>	<span style="color: red;">●</span>	<input checked="" type="checkbox"/>	10 mbps	half	MDI	<input type="checkbox"/>	TX-Port 4
5		<input checked="" type="checkbox"/>	<span style="color: red;">●</span>	<input checked="" type="checkbox"/>	10 mbps	half	MDI	<input type="checkbox"/>	TX-Port 5
6		<input checked="" type="checkbox"/>	<span style="color: red;">●</span>	<input checked="" type="checkbox"/>	10 mbps	half	MDI	<input type="checkbox"/>	TX-Port 6
7		<input checked="" type="checkbox"/>	<span style="color: green;">●</span>	<input checked="" type="checkbox"/>	1000 mbps	full	MDI	<input type="checkbox"/>	TX-Port 7
8		<input checked="" type="checkbox"/>	<span style="color: green;">●</span>	<input checked="" type="checkbox"/>	1000 mbps	full	MDI	<input type="checkbox"/>	TX-Port 8
9		<input checked="" type="checkbox"/>	<span style="color: grey;">●</span>		1000 mbps	full		<input type="checkbox"/>	FX-Port 9
10		<input checked="" type="checkbox"/>	<span style="color: grey;">●</span>		1000 mbps	full		<input type="checkbox"/>	FX-Port 10

Figure 13: Overview of the port configuration table

The following columns are displayed:

- » Port: Indicates the port number, which is also labeled on the enclosure (P1 to P8).
- » Type: Indicates via the help symbol if the port is an RJ45 port or an optical port.
- » Activated: The individual ports can be activated or deactivated here. This specifies whether a port is able to be used or not.
- » Status: Status signals the current status of the ports:
  - Green: The port is activated and a connection is present.
  - Red: The port is activated, but there is no connection.
  - Grey: The port is deactivated. A connection is not possible.

	<h1>Operating Manual</h1>	MAN_EL-1000-4GM
		Version: 2.6.1 / 01.02.2021
		Authorized by: T.W.
		Page 46 of 77

- Green/yellow: The LWL port is active and a connection is present. The path should be checked.

» Auto Negotiation: If this function is activated, the configuration of transfer speed and duplex mode via the *EL-1000-4GM* and the connected recipient will take place automatically. If Auto Negotiation is deactivated, then the settings can be set manually, and the communicating devices must work with these settings:

- Speed: The data rate of the ports can be assigned permanently. The option of setting a data rate 10 mbps, 100 mbps or 1000 mbps is possible.
- Duplex: Duplex modus can be switched between half and full duplex. This setting is therefore specified permanently for a connection.

**Note:** If both link partners use Auto Negotiation, then it cannot be guaranteed that the link partners will settle on full duplex. There will also be a duplex mismatch with output impairment if one link partner uses Auto Negotiation and the other is set permanently. We recommend setting link partners permanently to one speed and one duplex mode.

» MDI(X): The *EL-1000-4GM* switch may complete an auto-crossover by default. This means that the switch independently recognizes whether a subscriber is connected via a crossed or uncrossed cable.

» Flow control: The flow control ensures that overloading at a port signals to the opposite subscriber that it should send slower. If QoS (Quality of Service) is used, then the flow control should be deactivated.

» Designation: You can give the ports a name in this column. The names are displayed during the complete configuration and facilitate selection of the correct settings and diagnosis in case of an error. The port designations can be edited directly in the row where they are displayed.

## 5.6.1 Port Mirroring


Port Mirroring (Figure 14) is a method for mirroring the data traffic of a port in a network (source) on a second port (target) in order to analyze it. Either only sent or sent and received packets are able to be mirrored. The following settings can be made:

- Port and port name: All of the ports are displayed here in order to select a target and one or multiple source ports.
- Target port: If port mirroring is active, then the port can be selected here to which the data should be duplicated.
- The source port indicates from which ports sent (TX) or sent and received (TX and RX) data packets should be forwarded to the target port.

After you have set the respective parameters, click the apply button to save and apply the settings.

**Note:**


Deactivate port mirroring in normal mode and only apply it for problem analysis.



The screenshot shows the 'Port Mirroring' configuration page. At the top, there is a status bar with 'ON' and 'Current Status: active'. Below this is a table with the following structure:

Port	Port name	Destination	Source Port	
			TX only	TX and RX
1	TX-Port 1	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
2	TX-Port 2	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
3	TX-Port 3	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
4	TX-Port 4	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
5	TX-Port 5	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
6	TX-Port 6	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
7	TX-Port 7	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
8	TX-Port 8	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
9	FX-Port 9	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
10	FX-Port 10	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

**Figure 14: Port Mirroring**

	<h1>Operating Manual</h1>	MAN_EL-1000-4GM
		Version: 2.6.1 / 01.02.2021
		Authorized by: T.W.
		Page 48 of 77

## 5.7 Redundancy

The redundancy screen offers an overview of the available redundancy protocols and their status. It isn't possible to activate multiple redundancy protocols at the same time, which is why only one may possess active status. The edit button can be used to access the protocols, where the configuration can be made.

The following protocols are available:

- » MRP: Media Redundancy Protocol
- » RSTP: Rapid Spanning Tree Protocol

Use of the redundancy protocols guarantees your network increased failure security and availability in case of faults.

### 5.7.1 Media Redundancy Protocol (MRP)

The Media Redundancy Protocol (Figure 15) is a ring protocol for highly available networks. The MRP switches form a ring via the two respective dedicated ports. Exactly one switch in the ring is configured as a redundancy manager. This redundancy manager uses special test packets to test the flow capacity of the ring and completes a redundant connection if the ring is interrupted by a fault. The guaranteed reconfiguration time for up to 50 devices in the ring amounts to 200 ms. In a typical application, the reconfiguration time normally amounts to less than 50 ms.

**Attention!** The ring may only physically be completed if MRP is configured completely.

#### Ring configuration



The following settings are required for MRP:

- First ring port: Please select a port that should work as the primary ring port.
- Second ring port: Specify a second port that should work as the secondary ring port. Please note that the secondary ring port cannot simultaneously function as the primary ring port.
- Ring Settings: Please specify whether the *EL-1000-4GM* should act as manager or client. Please note that only one manager can be used for each ring.




Figure 15: Media Redundancy protocol (MRP)

## 5.7.2 Rapid Spanning Tree Protocol (RSTP)

The Rapid Spanning Tree Protocol (RSTP) (Figure 16 and Figure 17) is a standardized method that can be used to establish network structures including a ring. The protocol breaks the network into a logical tree and deactivates redundant paths or activates them as required. The first step is to select a root bridge, which depicts the root of the tree to be created. Starting from the root bridge, the path to all of the other bridges in the network is specified. The paths that can be used for communication are detected via the path costs to the individual bridges.




Figure 16: Rapid Spanning Tree Protocol – device settings

## Root Bridge Information

The following parameters are displayed in this field:

- Root port: Shows which port works as the root port, i.e. the connection with the lowest path costs to the root bridge.
- Root bridge ID: The bridge ID is a combination of bridge priority and MAC address of a bridge. The bridge with the lowest bridge ID is selected as the root bridge. The Root bridge ID is the bridge ID of the selected root bridge.
- Designated cost: Path costs for root bridge
- Root bridge MAC address: Displays the MAC address of the root bridge.

## RSTP settings

In order to discover the RSTP tree, every port of the switch completes a process involving the port states before the ports transfer useful data. The time span that the ports remain in the individual states is specified by timers. Under RSTP settings, the following can be adjusted:

- » Forward Delay: The waiting time before a port switches from the status Learning/Listening (still no transfer of useful data) to Forwarding (transfer of useful data). A time between 4 s and 30 s can be entered. The basic setting features a forward delay of 15 s.
- » Maximum Age: The time that a bridge waits before attempting a new configuration if it does not receive messages from the Spanning Tree configuration protocol. A time between 6 s and 40 s can be entered. In the basic setting, the Maximum Age amounts to 20 seconds.
- » Bridge Priority: This value is used to specify the root bridge. The bridge with the lowest value selected as the root bridge. The value must be between 0 and 61440 and a multiple of 4096. Changes to this value require a switch restart.
- » Hello Time: The time in which the switch sends a BPDU packet (Bridge Protocol Data Unit) to check the current status of the RSTP. A time between 1 s and 10 s can be entered. The basic setting for the Hello Time is 2 s.
- » TX Hold Count: The maximum number of hello packets of an interval transferred. Between 1 and 10 packets can be selected. In the basic setting, the TX Hold Count amounts to 3.


**Note:** Observe the following rules to configure the forward delay, maximum age, and hello time:

$$2 * (\text{Forward Delay Time} - 1) \geq \text{Maximum age} \geq 2 * (\text{Hello Time} + 1).$$

Recommended approach: Select a value for the "Hello Time" and calculate using the formula  $2 * (\text{Hello Time} + 1)$  according to the rule indicated above to determine the lower limit for the Maximum Age. Select a value for the "Forward Delay Time" and calculate using the formula  $2 * (\text{Forward Delay Time} - 1)$  according to the rule indicated above to determine the upper limit for the Maximum Age. Select a maximum age between 6 and 40 seconds between the calculated limits.

After clicking apply, the RSTP protocol reconfigures itself and indicates any possibly changed root bridge parameters in the top part of the screen.

## 5.7.2.1.1 Port settings



**Rapid Spanning Tree Protocol (RSTP)**

ON Current Status ✘ inactive

Port	RSTP on	Status	Role	Priority	Cost		Edge port	
					defined	designated	force	auto
1	<input checked="" type="checkbox"/>	forwarding		128	200000	0	<input type="checkbox"/>	<input type="checkbox"/>
2	<input checked="" type="checkbox"/>	forwarding		128	200000	0	<input type="checkbox"/>	<input type="checkbox"/>
3	<input checked="" type="checkbox"/>	forwarding		128	200000	0	<input type="checkbox"/>	<input type="checkbox"/>
4	<input checked="" type="checkbox"/>	forwarding		128	200000	0	<input type="checkbox"/>	<input type="checkbox"/>
5	<input checked="" type="checkbox"/>	forwarding		128	200000	0	<input type="checkbox"/>	<input type="checkbox"/>
6	<input checked="" type="checkbox"/>	forwarding		128	200000	0	<input type="checkbox"/>	<input type="checkbox"/>
7	<input checked="" type="checkbox"/>	forwarding		128	200000	0	<input type="checkbox"/>	<input type="checkbox"/>
8	<input checked="" type="checkbox"/>	forwarding		128	20000	0	<input type="checkbox"/>	<input type="checkbox"/>

Apply Cancel

**Figure 17: Rapid Spanning Tree Protocol – port settings**

The port settings screen tab enables the following settings to be made:

- » Port: Displays the port number.
- » RSTP on: RSTP can be activated or deactivated for each port.
- » Status: This column displays the status of the individual ports. This is differentiated between:
  - Blocking: Discards packets; does not learn addresses; does not receive and processes BPDUs (Bridge Protocol Data Units = RSTP protocol packets)
  - Listening: Discards packets; does not learn addresses; receives, processes, and transfers BPDUs
  - Learning: Discards packets; learns addresses; receives, processes, and transfers BPDUs
  - Forwarding: Forwards packets; learns addresses; receives, processes, and transfers BPDUs
  - Disabled: Discards packets; does not learn addresses; does not receive and process BPDUs
- » Role: According to IEEE 802.1D-2004, each port is able to run in one of the following modes:
  - Root Port: A port in the forwarding state that was selected for the best tree structure.
  - Designated Port: A port in the forwarding state that has been selected for any switched LAN segment.

- **Alternative Port:** An alternative port to the root bridge that is also available in addition to the current root port.
- **Backup Port:** A reserve path that is provided via a designated port in the direction of the branches of the tree structure.
- **Deactivated Port:** A port that does not have any operating function in the tree structure.
- » **Priority:** Decides which port is treated with priority if the path costs to multiple ports are the same. Priority must be a multiple of 16 between 0 and 240.
- » **Costs:** The path costs from this bridge to the opposite bridge. The costs can be between 1 and 200,000,000.
  - **Defined:** The costs of the connection to the root bridge can be specified to include cable lengths or maximum data rates.
  - **Designed:** Calculated path costs.
- » **Edge port:** Indicates a port that is connected directly with an end station. These ports cannot cause loops and therefore immediately change to forwarding mode. The status change of an edge port will not lead to a change in the topology.
  - **Force:** The port is configured by default as an edge port.
  - **Auto:** The configuration as edge port takes place automatically.

After setting the RSTP parameters, these must be saved by clicking the apply button.

## 5.8 Industrial Protocols

### 5.8.1 Profinet

Profinet is the abbreviation for Process Field Network and describes the open industrial Ethernet-standard for the automation. The *EL-1000-4GM* switch is developed as a Profinet IO-Device for the connection of decentralized periphery to a Profinet controller. The device supports conformance class B and Netload Class III.

On the webpage you can activate the Profinet functionality and the other settings.

GSD-File: The downloadable configuration file offers the device description of the Profinet field device. The file is in xml format, can be downloaded directly from the device and is available from the manufacturer on request.

The file includes information needed during project planning with the Profinet controller.

Attention! For proper operation in a Profinet network we highly recommend that the Quality of Service feature is enabled and configured to use class based scheduling of traffic (Class of Service First or Class of Service only) and enable the weighted fair queuing priority setting. The Traffic Classes 6 (Internetwork Control) and 7 (Network Control) should be set to highest priority. Please also check chapter 5.9.3.

The screenshot displays the Profinet configuration page. At the top right, system information is shown: Name of Station: dut, Device Location: gnar, IP Address: 192.168.10.1, and user: admin. The main content area is titled 'Profinet' and features a green 'ON' toggle switch. Below the toggle, the 'Current Status' is indicated as 'active' with a green checkmark. The 'PNIO AR Status' is 'Offline' and the 'PNIO Device name' is 'dut'. The 'Controller MAC' is '00:00:00:00:00:00' and the 'Controller' field is empty. The 'DCP Configuration' table is as follows:

Port	enable DCP-TX	Port name
1	<input checked="" type="checkbox"/>	TX-Port 1
2	<input checked="" type="checkbox"/>	TX-Port 2
3	<input checked="" type="checkbox"/>	TX-Port 3
4	<input checked="" type="checkbox"/>	TX-Port 4
5	<input checked="" type="checkbox"/>	TX-Port 5
6	<input checked="" type="checkbox"/>	TX-Port 6
7	<input checked="" type="checkbox"/>	TX-Port 7
8	<input checked="" type="checkbox"/>	TX-Port 8
9	<input checked="" type="checkbox"/>	FX-Port 9

Additional Information: This device supports Profinet Conformance Class B. Download GSDML-File [here](#).

Figure 18: Profinet and DCP configuration

## 5.9 Switching

The switching screen offers an overview of activated and deactivated functions in the switching area.

**Aging Time:** This indicates the period of time during which a MAC address remains after removal from the port or switching of the device. You can select values between 16 and 4080 seconds in steps of 16 seconds. The default value is 304 seconds.

### 5.9.1 IGMP Snooping

The Internet Group Management Protocol (IGMP) is used by switches, routers, and hosts to set up multi-cast groups. If IGMP is activated, multi-cast data traffic does not need to be sent to every individual multi-cast receiver, but rather only to each group. This severely reduces the network load. IGMP snooping works on Layer 3 of the OSI model and is extended by the Layer 2 protocol IGMP snooping (Figure 19). IGMP snooping listens to the IGMP data traffic and learns via which ports the multi-cast data must be sent.

#### IGMP snooping settings

The following settings are displayed and can be adjusted:

- » VLAN ID: IGMP snooping operates on VLAN basis and can be activated for each individual VLAN ID.
- » Fast Leaver: If a multi-cast group should be removed, then there is normally a query whether no subscriber is really available in the group (query message). Fast Leaver is a port that removes a multi-cast group without any additional query. This setting is interesting for ports that are only connected with one multi-cast receiver.
- » Learned Ports: Shows which ports are connected with multi-cast receivers and which ports should be forwarded the corresponding multi-cast data.
- » Static Ports: Freely configurable ports that should always receive multi-cast data independent of IGMP messages.
- » VLAN name: The name of VLANs.




Figure 195: IGMP Snooping

## Additional Settings

- » Activate querier: If no multi-cast router is present in the VLAN and the IGMP queries are sent, you can configure here that query packets should be created from this switch.
- » Suppress report: If receivers join multi-cast groups or leave them, then they transfer status reports to the IGMP protocol. This status data can be bundled by the IGMP snooping protocol by activating "suppress report". By limiting the necessary reports, the network load is reduced.

### 5.9.2 VLAN 802.1Q

A virtual LAN (VLAN) is a group of ports that may be somewhere in the network, but communicate as if they were in the same area. VLANs can be used to separate departments (R&D, marketing), applications (e.g. E-mail), or multi-cast groups for video transfers, which thereby simplifies network management.

In case of VLAN as per 802.1Q, Ethernet-data packet feature a VLAN tag, an extension, which includes a VLAN-ID, a clear number for the VLAN that the data packet belongs to. Which ports should send data Packets of VLAN with a VLAN tag and which ports should send data packets of a VLAN without a VLAN tag can be configured comfortably in the VLAN web interface menu (Figure 20). In addition to this, VLANs are added using the "+" buttons or the following settings can be changed via editing



with the edit button:

- VLAN ID: This identification number is clearly assigned to a VLAN. VLAN IDs between 1 and 4094 are possible.
- VLAN name: Any name for the VLAN.
- VLAN packets are sent to untagged ports without a VLAN tag.
- VLAN packets are sent to tagged ports with a VLAN tag.




Figure 20: VLAN 802.1

Use the delete button to remove any VLANs except for the default VLAN (VLAN ID 1).

## Use of VLANs as per VLAN 802.1Q

If data packets that do not include a VLAN tag are received by a port, then they receive the VLAN-ID of the VLAN for internal processing that is configured as the untagged receiver port. Each port may therefore be configured as untagged for a VLAN. If data packets are received that contain a VLAN tag, then these are discarded if their VLAN-ID does not correspond with the default VLAN-ID or the VLAN-ID of a VLAN that is assigned to the receiving location tagged or untagged.

All incoming data packets therefore possess a VLAN-ID internally. This internal VLAN-ID decides which ports the data packets are exported on. The data of the default VLAN is exported to all ports, while the data of other VLANs are only exported to ports that are assigned to the VLAN with the VLAN-ID of the data packets.


If the data packets are sent with or without a VLAN tag is decided by the type of port assignment to the VLAN. If a port is assigned to a VLAN tagged, then data packets are sent with the VLAN-ID of the VLAN on the corresponding port with a VLAN tag. If the VLAN is assigned untagged, then the packets are sent on the port without a VLAN tag.

**Attention!** Packets of the default VLAN are output to all ports. The default VLAN should therefore be used for management packets. Ports without a VLAN assignment must be assigned to a VLAN that is not used so that packets that are received on these ports are not able to enter the default VLAN (see ).

**Attention!** Packets with the VLAN tag 1 are received on all ports and output to all ports.

## 5.9.3 Quality of Service (QoS)

Quality of Service (Figure 21) influences the data traffic in the switch so that services are available to the receiver with a specified quality. In addition to this, data packets are sorted depending on different priority processes (port-based, class of service, type of service) into four priority queues, which are emptied at the exit corresponding with a priority mode (strictly and weighted).



Port	Port name	priority			
		high	medium	normal	low
1	TX-Port 1	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>
2	TX-Port 2	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>
3	TX-Port 3	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>
4	TX-Port 4	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>
5	TX-Port 5	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>
6	TX-Port 6	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>
7	TX-Port 7	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>
8	TX-Port 8	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>

Figure 21: Quality of Service

### Priority process

The following priority processes can be selected:

- Port-based only: The priority takes place exclusively based on the port priority.
- Class of Service (CoS) only: The priority takes place based on the CoS fields in the VLAN tag of the data packets. Non VLAN packets are guided to the priority queue with the lowest priority.
- Type of Service (ToS) only: The priority takes place based on the ToS fields in the IP header of the IP data packets. Packets without ToS field or non-IP packets are guided into the priority queue with the lowest priority.

- » Class of Service first: Packets with COS information in the VLAN tag are prioritized after this. Packets without CoS information are prioritized according to the ToS field in the IP header or according to port priority in case of a missing ToS field.
- » Type of Service first: Packets with ToS field in the IP header are prioritized after this. Packets without ToS information are prioritized according to the CoS field in the VLAN tag or according to port priority in case of a missing VLAN tag.

### Output: Priority mode

- » Strict priority diagram: In case of a strict priority diagram, all of the packets from the higher priority queue are sent first, and then packets from the next lower priority queue are sent.
- » 8-4-2-1 weighted sequence: After 8 packets in the highest priority queue have been sent, 4 packets in the second-highest, 2 packets in the third-highest, and 1 packet in the lowest priority queue will be sent. This approach avoids extreme waiting times for packets with the lowest priority.

**Note:** If Quality of Service is used, the flow control must be switched off, since activated flow control will transfer data packets throttled and independent of the priority (see section 5.6).

**Attention!** If the device is used in a Profinet setup it is highly recommended to enable the Quality of Service feature and use a weighted fair scheduling (8-4-2-1 Priority Mode). Furthermore either COS only mode or COS first mode with highest priority for traffic classes 6 (Internetwork Control) and 7 (Network Control) should be configured in order to allow secure and reliable communication in automation networks.

## 5.9.4 Rate Control

The rate control feature (Figure 22) can be used to limit different types of packets to an adjustable data rate. This can be used, for example, to ensure that an excessive number of broadcast packets (packets that are sent to all subscribers) do not disturb the normal Unicast data traffic (packets that are only sent to one subscriber).

**Rate Control**

ON Current Status ✘ inactive

Rate Control settings

Port	Port name	Ingress Packet Type	Ingress Limit	Egress limit
1	TX-Port 1	all	no limit	no limit
2	TX-Port 2	all	no limit	no limit
3	TX-Port 3	all	no limit	no limit
4	TX-Port 4	all	no limit	no limit
5	TX-Port 5	all	no limit	no limit
6	TX-Port 6	all	no limit	no limit
7	TX-Port 7	all	no limit	no limit
8	TX-Port 8	all	no limit	no limit
9	FX-Port 9	all	no limit	no limit
10	FX-Port 10	all	no limit	no limit


Apply Cancel

**Figure 22: Rate Control settings**

The following settings can be made:

- Port: Indicates the port number.
- Type of incoming packets: Indicates which types of data packets should be limited:
  - All: All packets are limited.
  - Broadcasts: Only broadcast packets are limited.
  - Multi-casts: Only multi-cast packets (packets to receiver groups) are limited.
  - Unknown Unicasts: Only Unicast packets from unknown receivers are limited.
- Limit incoming packets: The data rate limits of incoming data. 128 kbps, 256 kbps, 512 kbps, 1 mbps, 2 mbps, 4 mbps and 8 mbps are possible. "No limit" is defined as a standard value.

	<h1>Operating Manual</h1>	MAN_EL-1000-4GM
		Version: 2.6.1 / 01.02.2021
		Authorized by: T.W.
		Page 62 of 77

 Limit outgoing packets: The data rates limits for outgoing packets. These always relate to all packet types. 128 kbps, 256 kbps, 512 kbps, 1 mbps, 2 mbps, 4 mbps and 8 mbps are possible. "No limit" is defined as a standard value.

The desired settings can be saved by pressing the apply button.

## 5.10 Access

The access menu item (Figure 23) is used to specify the paths that will be used to access the **EL-1000-4GM** switch.

- **Ping:** In order to check if the device is able to be reached in your network, you can send queries to the device, which will send a response. The responses to these ping packets are suppressed if you deactivate ping under access.
- **Device Identifier:** In order to be able to identify the device in a network cabinet, it is possible with the Device Identifier to let the Status, Fail & Ring LED flash for 30 seconds.




Figure 23: Selection of access options

### Settings

The time until automatic logout specifies how long a session remains in the web management without activity until an automatic logout takes place. The time can be configured between 3 minutes and 30 minutes.

The apply button can be used to save the settings.

## 5.10.1 Simple Network Management Protocol (SNMP)

The Simple Network Management Protocol (SNMP) is used to monitor and control network elements via a central station. Which settings in a network element can be changed and which values can be queried is not defined in the SNMP, but rather in the so-called MIBs (Management Information Base). In addition to several generally applicable MIBs, most of the devices also feature manufacturer-specific MIBs with device-specific information. SNMP queries are sent from the management station with a so-called community string, which represents a simple access limit. Responses are only provided for queries featuring a community string that matches a community string that is defined in the switch. Because the community string is sent in plain text via the network, its use does not necessarily increase the security.




Figure 24: Overview of currently available SNMP accesses

### SNMP accesses


In the SNMP menu (Figure 24) of the **EL-1000-4GM** switch, community strings can be added, edited, or deleted. The following settings can be configured in this case:



- » Active: Shows which strings are active at which community and which are not
- » Community string: The accesses are defined via a clear name, which can be set here. A name may feature a maximum 32 characters.
- » Read only: Queries with this community string are answered, but they cannot adjust settings at the switch.
- » Read and write: Queries with this community string are answered and may adjust settings at the switch.
- » Remove: Delete the community strings

The **EL-1000-4GM** supports SNMP versions V1 and V2C. Please select the desired version.

Save the settings by clicking the "create" button.

	<h1>Operating Manual</h1>	MAN_EL-1000-4GM
		Version: 2.6.1 / 01.02.2021
		Authorized by: T.W.
		Page 66 of 77

## 5.11 Maintenance

The maintenance menu item is divided into the items backup, restore, firmware update, factory settings, and restart, which are described in the following.

### 5.11.1 Backup

This menu item offers you the option to save the current configuration of the **EL-1000-4GM** as a file. The backup can be stored via TFTP-server (Trivial File Transfer Protocol), as download or via usb-device. In connection with restoring, the backup function enables you to save all settings and reload them later to the device or use the current configuration in other devices.

The device creates a file with all settings. You have to store this file and can load it again to the device with the restore function.

In order to save the configuration via TFTP, a TFTP server must be set up on a computer in the network. Various TFTP server programs are available for download as freeware on the Internet.

#### Einstellungen TFTP

» TFTP Server IP address: IP address of the TFTP server available in the network in decimal point notation.

#### Settings TFTP, USB or HTTP

» File name: File name of the switch configuration file to be saved.

If the parameters have been entered correctly, the backup can be executed by clicking on "Start backup".

### 5.11.2 Restore

This menu item is used to import a configuration that was previously saved as a backup file. It can be loaded via tftp-server, as an upload or via usb-device.




Figure 25: Settings for restoring a configuration

## TFTP Settings

» TFTP Server IP address: IP address of the TFTP server available in the network in decimal point notation.

## Settings TFTP, USB, or HTTP

- » Filename: The filename of the switch configuration file stored on the TFTP server.
- » Password: Specifies whether the current password settings should be retained when restoring the configuration or whether they should be overwritten with the settings from the configuration file.
- » IP configuration: Specifies whether the currently set IP address, subnet mask and gate way should be retained or overwritten with the settings from the configuration file.

Press the button "Start restore" to start the restore process. Doublecheck the settings in the popup window and confirm to reload the settings. After the process is done the device will reboot.

	<h1>Operating Manual</h1>	MAN_EL-1000-4GM
		Version: 2.6.1 / 01.02.2021
		Authorized by: T.W.
		Page 68 of 77

### 5.11.3 Restore via USB stick

The **EL-1000-4GM** switch may also be restored without web interface access, provided a USB stick with a configuration file is present while the device is starting. The file name of the configuration file decides if the IP configuration of the switch should be overwritten or not.

If the configuration file configWithoutIp.bin is present on the USB-Drive (in the root folder) while the device is starting, all **EL-1000-4GM** settings up to the IP configuration are replaced by the settings from the file. If the file is not available and a configWithIp.bin is not available on the USB stick, then all of the settings of the **EL-1000-4GM** including the IP configuration will be replaced with the settings from this file.

If one of these configuration files is available, the **EL-1000-4GM** switch several seconds after starting up with the settings from the configuration file. This is indicated when all of the LEDs light up again. The file is removed after a successful restore process.

The password settings are always kept for this type of configuration. If both files are present on the USB-Drive the file configWithoutIp.bin will be used.

### 5.11.4 Firmware update

The menu item firmware update can be used to update the firmware of the **EL-1000-4GM**. Please only use firmware versions that are recommended by eks Engel FOS GmbH & Co. KG and have been developed for the devices of the **EL-1000-4GM** series. Before starting the update process it is important to stop the redundancy protocols and to open the MRP ring. The device can get the new firmware by downloading it from a directly connected USB-Device or a TFTP-Server, which is accessible in the network. With the option upload it is possible to use a firmware which is stored on the computer or server in your network and store it on the **EL-1000-4GM**.

**Attention!** Please do not complete this action if you have not been authorized to do so by the manufacturer beforehand. This function should only be used if problems occur that are only able to be corrected by changing the device software. For this reason, you will only receive new or changed firmware if the manufacturer considers it to be necessary.

## Update via TFTP-Server

To update the firmware by using a TFTP-Server, the new firmware file has to be stored in the TFTP-Server root directory. Please write down the name of the file or remember it. Now open the web interface of the **EL-1000-4GM** and choose Firmware update over TFTP. Insert the IP-Address (Version 4) of the TFTP-Server in the field "TFTP-Server IP Address" and the name of the firmware file in the field filename. Press the button "Start Firmware update" to install the new firmware on the device.

## Update via Upload

Press the button "select file" and a new window will open and show you the content of your computer. Select the firmware file and press the button open, to upload the file to the **EL-1000-4GM**. The upload of the firmware file will start and you can see the progress status. When the upload has finished the progress window will close and you can check the name of the uploaded file in the field Filename. Press the button "Start Firmware update" to install the new firmware on the device.


## Update via USB

To update the firmware by using the usb-function store the file with the new firmware in an usb-device and write down or remember the name of the file. Connect the usb-device to the **EL-1000-4GM** and choose the point Firmware update over usb. Insert the name and extensions of the file in the field filename. Press the button "Start Firmware update" to install the new firmware on the device.

**Attention.** Please follow these rules during the firmware update:

- » Do not disconnect the device from the supply voltage.
- » Do not disconnect or replace any network connections.
- » Do not press the reset button on the front side of the device.

During the update, a progress display appears in the web interface. As soon as the update is completed, the **EL-1000-4GM** switch will restart.

	<h1>Operating Manual</h1>	MAN_EL-1000-4GM
		Version: 2.6.1 / 01.02.2021
		Authorized by: T.W.
		Page 70 of 77

## 5.11.5 Factory settings

This menu item is used to reset the device to the factory settings.

### Settings:

- » Password: Specifies whether the password settings should be maintained if the configuration is reset or if they should be overwritten with the factory settings.
- » IP configuration: Specifies whether the IP address, subnet mask, and gateway should be maintained or if they should be overwritten with the factory settings.

By clicking the "Set factory settings" button, the **EL-1000-4GM** switch is reset.

## 5.11.6 Reboot

A reboot or software reset can be executed here. By clicking the reboot button, the switch's program is stopped and the device is rebooted.

The reset switch on the front side of the device has the same function and restarts the software, see section Reset button. Alternatively, you can switch both supply voltages of the switch on and off to complete a hardware reset.

## 5.11.7 Licenses

### Manufacturer information

If you have serious problems with the configuration of the device or questions about the device, please contact eks Engel FOS GmbH & Co. KG. Please read the online help of the device and the instructions before contacting support.

### User manual

You can download the current operating instructions as a PDF document directly from the device. You can find a suitable PDF reader free of charge on the Internet.

### SNMP - Management Information Base

The Management Information Base provides all device-specific information that can be read from the device with an SNMP browser.

## License information

The device contains open source software. In the license.txt file you will find information on all licenses to be observed.

## Profinet GSD file

The GSD-file describes the functionality of the **EL-1000-4GM** to integrate the device into the profinet environment. The GSDML-File (generic station description markup language) is a xml-file which is language independent.

## SNMP MIB file

The SNMP MIB (**S**imple **N**etwork **M**anagement **P**rotocol - **M**anagement **I**nformation **B**ase) file is available for download on the device.

	<h1>Operating Manual</h1>	MAN_EL-1000-4GM
		Version: 2.6.1 / 01.02.2021
		Authorized by: T.W.
		Page 72 of 77

## 6 Monitoring of the ambient air temperature

---

The device may only be operated up to the maximum ambient air temperature specified in the "Technical specification" chapter (air temperature 5 cm next to the device). It depends on the installation conditions of the device (e.g. : performance of neighboring devices, distance to other devices or objects). The temperature displayed in the web interface is the internal temperature of the device and higher than the temperature of the ambient air.

## 7 Instructions for troubleshooting

---


- » Check the correct voltage supply. One of the VDC LEDs must be glowing green.
- » Check the link/act LEDs of the wired RJ45 sockets and the optical fiber cable transceiver. If the connection is established, the link LEDs will light up, and they will flash in case data is being transmitted.
- » Check the wiring of the RJ45 sockets. Select the correct network cable. Use "unshielded twisted pair" (UTP) or "shielded twisted pair" (STP) for RJ45 connections to establish the network: 100Ω category 3, 4, 5 or better cables for connections with 10 mbps or 100Ω category 5 or better cables for connections with 100 mbps. Make sure that the cables are no longer than 100 meters.
- » In case of doubt, disconnect redundant network structures and set the **EL-1000-4GM** switch to the factory settings. If the communication functions, enter your settings gradually and observe which settings result in the error.



## 8 Technical specifications

8TX, 2FX	EL1000-4GM-8TX-2FX-MM-SC		EL100-4GM-8TX-2FX-SM-SC
1000 FX Ports	2 x 1000SX SC		2 x 1000LX SC
Fibertype	Multimode		Singlemode
Fibertype	50/125 µm	62,5/125 µm	9/125 µm
Typical Attenuation	1 dB/km		0,3dB/km
Wavelength	850 nm		1310 nm
Budget	7,5 dB		10,5 dB
Max.-Distance	550 m	275 m	10 km (andere auf Anfrage)
6TX, 2SFP	EL100-4GM-6TX-2SFP		
Item Number	05106109999		

10/100/1000 Base Tx-Ports	RJ45 / auto-negotiation / Auto MDI / MDI-X / Supports cables up to 100m
Power supply	12-60 VDC redundant voltage supply
Power consumption	Maximum 8 W
Electrical isolation	500 V
Dimensions	W: 30mm, H: 165mm, D: 101mm
Weight	500 g
Enclosure	Stainless steel, powder-coated
Storage temperature	-40°C – +85°C
Operating temperature	-40°C – +60°C
Humidity	Moisture 5-95% RHD non-condensing
EMC	EN 61000-6-2 / EN 55032 Class A
LED display	Error LED (red) / port LEDs (yellow / green) / voltage supply (green) / ring LED(green) / status LED (green)
IEEE	IEEE 802.3 10Base-T Ethernet / IEEE 802.3u 100Base-TX und 802.3z Gigabit Ethernet / IEEE 802.3ab 1000Base-T Gigabit-Ethernet / IEEE802.1d spanning tree / IEEE802.1w rapid spanning tree / IEEE802.1p class of service / IEEE802.1Q VLAN Tag
Protocol	PROFINET Class B, Netload Class III
Management	SNMP management Web interface management
SNMP MIB	RFC 1213 MIBII / RFC 1493 Bridge MIB / RMON RFC 1757 / RFC 2674 VLAN MIB / RFC 1643 EtherLike-MIB / RFC 1215 Trap MIB Private MIB for switch information, ring, port alarm, TFTP firmware update, reset, port mirror, IP security management, IGMP management MIB
Technology	Store and forward switching architecture, Profinet Class B, Netload Class III
SNMP trap	Trap receiver / cold start / port link up / port link down / authentication fault / private trap for power status / port alarm configuration / fault alarm ring
Transfer rate	14,880 pps for 10Base-T Ethernet Port 148,800 pps for 100Base-TX/FX Fast Ethernet Port 1,488,000 pps for 1000Base-T Ethernet Port
MAC address table	2K MAC address table

	<h1>Operating Manual</h1>	MAN_EL-1000-4GM
		Version: 2.6.1 / 01.02.2021
		Authorized by: T.W.
		Page 74 of 77
<b>Packet filters</b>	4 types of packet filter rules with different packet combinations	
<b>Ring</b>	2 ports for the ring in order to guarantee a recovery time below 200 ms	
<b>VLAN</b>	Port-based VLAN Tagged VLAN IEEE 802.1Q	
<b>Class of Service</b>	IEEE802.1p Class of Service with 4 priority queues per port	
<b>Spanning Tree</b>	IEEE802.1d Spanning Tree and IEEE802.1w Rapid Spanning Tree	
<b>IGMP</b>	IGMP v1 and query mode with up to 256 groups	
<b>SNTP</b>	SNTP for time synchronization	
<b>SMTP</b>	SMTP server and e-mail accounts for event messages	
<b>Port Mirror</b>	Only TX packets or TX and RX packets	
<b>Firmware Update</b>	Firmware update, TFTP backup and restore via TFTP, USB; HTTP	
<b>Alarm contact</b>	Relay contact 25 VDC (1A) / 60 VDC (0.3 A)	
<b>Bandwidth control</b>	Ingress and egress with combination options	
<b>DHCP Client</b>	DHCP client function to receive an IP address from the DHCP server	

## 9 GPL/LGPL guarantee and liability exclusion

The **EL-1000-4GM** switches from eks Engel GmbH & Co. KG (referred to as eks in the following) also include open source software components in addition to proprietary software. The open source software is provided to you according to the conditions of the GNU General Public License (GPL) and the GNU Lesser General Public License (LGPL) free of license fees. It was written by third parties and is subject to copyright. You are entitled to use open source software according to the conditions of the GPL or LGPL. In case of a conflict between eks license conditions and the conditions of the GPL or the LGPL, the GPL and LGPL shall apply to the open source components of the software.

The GPL and LGPL licenses and additional license information are available via the following URL on the device (IP address upon delivery):

<http://<insert-device-ip/download/license.txt>

If the source code of the open source software is not delivered with the **EL-1000-4GM**, then you may request it via the following e-mail address (together with the associated copyright instructions): [info@eks-engel.de](mailto:info@eks-engel.de). The source code will be sent to you for the price of copying and delivery costs.

	<h1>Operating Manual</h1>	MAN_EL-1000-4GM
		Version: 2.6.1 / 01.02.2021
		Authorized by: T.W.
		Page 75 of 77

All source code queries must be submitted within three years after purchasing the **EL-1000-4GM**. Please include a copy of the purchase receipt with your request. Please also include the exact name of the device and the version number of the installed software.

Use of the open source software delivered with **EL-1000-4GM** in any other way with the **EL-1000-4GM** hardware shall take place at your own risk without any liability claims against eks. For more information about guarantee claims involving the authors of the open source software delivered with the **EL-1000-4GM**, we refer to the GPL and the LGPL.

We exclude all liability for damage that results from any changes completed by third parties other than eks on parts of the software or the configuration. We exclude all liability on behalf of eks if the open source software violates copyrights of third parties. In case of changes that were not made to the software by eks, we shall not provide any technical support.

## 10 Table of figures

Figure 1: Front view of the <i>EL-1000-4GM</i> switch with 2 LWL transceivers	11
Figure 2: VDC connection terminal	16
Figure 3: Installation on DIN mounting rail	17
Figure 4: Dimensions of the <i>EL-1000-4GM</i> switch	19
Figure 5: <i>EL-1000-4GM</i> in a star-shaped network	23
Figure 6: <i>EL-1000-4GM</i> in a meshed network	24
Figure 7: <i>EL-1000-4GM</i> in a ring-shaped network	25
Figure 8: Login Window	27
Figure 9: Status and diagnosis	28
Figure 10: Alarms/notifications: Adding an alarm trigger	31
Figure 11: Adding an alarm receiver	32
Figure 12: Port statistics	34
Figure 13: Syslog messages	36
Figure 14: Link Layer Discovery protocol (LLDP)	38
Figure 15: The basic settings of the <i>EL-1000-4GM</i>	39
Figure 16: Changes to the IP configuration	41
Figure 17: Change the password for administrator and guest access	42
Figure 18: Time settings configuration	44
Figure 19: Overview of the port configuration table	45
Figure 20: Port Mirroring	47
Figure 21: Media Redundancy protocol (MRP)	49
Figure 22: Rapid Spanning Tree Protocol – device settings	50
Figure 23: Rapid Spanning Tree Protocol – port settings	52
Figure 24: Profinet and DCP configuration	54
Figure 25: IGMP Snooping	56
Figure 26: VLAN 802.1Q	57
Figure 27: Quality of Service	59
Figure 28: Rate Control settings	61
Figure 29: Selection of access options	63

Figure 30: Overview of currently available SNMP accesses 64

Figure 31: Settings for restoring a configuration 67